



Spare parts list for RET7532

Pos no		Chinese Description	English Description	QTY
1	RET7532-1	19垫片	Washer 19	2
2	RET7532-2	含油轴承	Oil bearing	2
3	RET7532-3	齿轮箱密封条	Gear case sealing strips	1
4	RET7532-4	齿轮箱左	left gear case	1
5	RET7532-5	19骨架密封圈	Rubber seal 19	2
6	RET7532-6	骨架密封圈挡板	Rubber seal guard	2
7	RET7532-7	自锁螺母M8	Nut	2
8	RET7532-8	刀片组件右	Blade Assy right	1
9	RET7532-9	自锁螺母M6	Mut	4
10	RET7532-10	外六角螺钉M8X40	Srew M8X40	2
11	RET7532-11	机壳座	Motor support plate	1
12	RET7532-12	电缆压板	Cable clamp	3
13	RET7532-13	十字槽盘头自攻螺钉	Srew ST4X16	25
14	RET7532-14	马车螺钉M6X20	Coach screw	4
15	RET7532-15	推杆塞子	Push rod plug	3
16	RET7532-16	花键连接轴套	Splined sleeve	1
17	RET7532-17	两脚电容 (线长80MM)	Capacitors	1
18	RET7532-18	转子定位板	Rotor locating plate	1
19	RET7532-19	单列向心球轴承6000	Ball bearing	1
20	RET7532-20	十字槽盘头螺钉	Srew M5X75	2
21	RET7532-21	弹性垫片	Washer	2
22	RET7532-22	电机前端	Motor front-end	1
23	RET7532-23	十字槽盘头自攻螺钉	Screw ST4X20	8
24	RET7532-24	定子组件	stator Assy	1
25	RET7532-25	温度保护开关	Thermal Protection Switch	1
26	RET7532-26	转子组件	Rotar Assy	1
27	RET7532-27	单列向心球轴承608	Ball bearing	2
28	RET7532-28	电刷插片	Brush insert	2
29	RET7532-29	圆型电感	Circular inductive	2
30	RET7532-30	十字槽盘头自攻螺钉	Screw ST3X8	2
31	RET7532-31	电刷	brush	2
32	RET7532-32	电刷架	brush frame	2
33	RET7532-33	六角加厚螺母S=5.5	Nut M5	2
34	RET7532-34	方型电感	square inductive	1
35	RET7532-35	电机后端	Motor back-end	1
36	RET7532-36	十字槽盘头尖头自攻螺钉	Screw ST4X16	2
37	RET7532-37	机壳	housing	1
38	RET7532-38	机壳盖	housing cover	1
39	RET7532-39	3号提手杆	No.3 Handle bar	1
40	RET7532-40	线定位夹	Cable clip	1
41	RET7532-41	马车螺钉M6X45	coach screw	4
42	RET7532-42	2号提手杆	No.2 Handle bar	1
43	RET7532-43	线夹	Cable clip	2
44	RET7532-44	提手杆旋钮	Knob	4
45	RET7532-45	1号提手杆右	No.1 Handle bar right	1
46	RET7532-46	花键连接轴	connecting shaft	1
47	RET7532-47	花键连接轴套	Splined sleeve	1
48	RET7532-48	14骨架密封圈	Rubber seal 14	1
49	RET7532-49	单列向心球轴承6001	Ball bearing	1
50	RET7532-50	平键	Flat key	1
51	RET7532-51	蜗轮轴	Worm wheel shaft	1
52	RET7532-52	蜗轮	Worm wheel	1
53	RET7532-53	蜗杆	Worm shaft	1
54	RET7532-54	齿轮箱右	right gear case	1
55	RET7532-55	弹性垫片6MM	washer	8
56	RET7532-56	内六角螺钉	Screw M6X18	8
57	RET7532-57	“O”型圈8mm	O ring	1

58	RET7532-58	内六角沉头螺钉	Screw M10X10	1	
59	RET7532-59	电源线连防水插头	Plug	1	
60	RET7532-60	四芯电源线	power line	1	
61	RET7532-61	开关盒压板	Switch box platen	1	
62	RET7532-62	护线套	retaining line sets	1	
63	RET7532-63	开关盒左	left Switch box	1	
64	RET7532-64	开关	Switch	1	
65	RET7532-65	开关盒连杆	Switch box Connecting Rod	1	
66	RET7532-66	开关扳手弹簧	Switch wrench spring	1	
67	RET7532-67	开关盒扳手	Switch box wrench	1	
68	RET7532-68	开关盒右	right Switch box	1	
69	RET7532-69	开关盒按钮弹簧	Switch box button spring	1	
70	RET7532-70	开关盒按钮	Switch box button	1	
71	RET7532-71	底座内圈海绵垫	sponge mat 1	1	
72	RET7532-72	刀片组件左	Blade Assy Left	1	
73	RET7532-73	1号提手杆左	No.1 Handle bar Left	1	
74	RET7532-74	波型垫圈	corrugated gasket	1	

#### Komplety

RET7532-A vypínač komplet

RET7532-B Převodovka komplet

RET7532-C motor komplet